VZ-R Firmware Update

First, download the Firmware .bin file here and save it to your desktop.

.bin Click Here

Please also note that you'll need a computer running Windows or Mac OS in order to perform this update.

1 Connect the VZ-R to your computer **via USB**.

2 Make sure that the VZ-R is **turned off**.

③ Make sure that **Visualizer is not running**.

④ Make sure that the VZ-R is **set to 6ohz**.


⑤ **Press and hold the filter button.**

⑥ **While pressing the filter button, turn on the VZ-R and hold until an external drive appears**. On a Mac, the drive will most likely appear on your Desktop as 'No Name'. In Windows, it will appear as an external drive.

⑦ **Copy the ApproSysFW.bin file into the drive.** In most cases, you can simply drag the .bin file and drop it in.

Copy

.bin

8 **After the copy is complete, please eject the drive.** On a Mac, you can simply drag the drive into the Trash. In Windows, you can right-click and eject.

Eject

9 **Turn off the VZ-R.**

10 **Turn the VZ-R back on and the white LED will flash multiple times.** This process will take about 1 minute to complete.

11 After the white LED stops flashing, you may open Visualizer and confirm that the VZ-R's firmware has been updated to **version 2014.** You can find the FW version in the Select Camera drop-down list.

Select Camera

VZ-R #1

FW Version : 2014
Refresh Rate : ● 60 Hz ○ 50 Hz
Brightness :
Contrast :
Gamma :